




Breville BKC600XL Spring Replacement

Replacing the spring should it fail to work.

Written By: Antonio



INTRODUCTION

Replacing the spring should it fail to work.



TOOLS:

- [Phillips #0 Screwdriver](#) (1)
- [Macbook Pro and Air 5-Point Pentalobe Screwdriver](#) (1)



PARTS:

- [Spring](#) (1)
-

Step 1 — "Bottom" Black Shell Piece




- Remove the following 2 screws:
 - Two 12mm black Truss Phillips screws.
- ☑ Reminder for reassembly; This bottom piece is first to be screwed back on.

Step 2 — "Top" Black Shell Piece




- Remove the two 12mm Phillips screws.

Step 3 — Silver Casing



- Remove the grey plastic casing.
- Remove the two 12mm hexagonal screws.

Step 4 — Spring



- Identify the spring and the hook its attached to.
- Carefully remove the spring.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-23 12:37:36 PM.